

Freeze Mitigation Process

Follow these steps to minimize the potential for damage to your system. This will not guarantee your system is protected from freeze damage. Pictures shown are typical but vary by system.

1. Call your irrigation company and schedule winterization blow out service.

2. Set controller to off.



3. Close valve in basement to irrigation system. It is usually located near the front of the home.

4. Set all test cocks and handles to 45° on backflow device which is usually located outside the home.

5. Open drain in basement near shut off valve to drain all water. You should expect a few ounces up to a gallon.

6. Wrap back flow device with towels/blankets and cover in plastic bag to keep dry.

